



717 768 0747

chickenrangecoop.com

Bell Waterer Owners Manual



Attach the water bucket holder to the upright brace on the end panel, using two U-bolts.



Hang the waterer from the ridge pole. Be sure the bottom will not rest on the grass.



unscrew here

The flow is adjusted by screwing the white part in, (more in the bowl) or out (less in the bowl) and locking it with the yellow nut.

After unhooking the yellow straps, remove the weight thru the bottom. Unscrew the yellow top and fill the weight 1/2 full with water. Put it together again. This will keep the waterer hanging straight and the valve will work better.



The valve assembly can be unscrewed from the waterer to clean. Unscrew the bottom to get to the valve. (AAA022).